




Key:

- StrataPlan SF Membrane 
- Hot Air Welding 
- StrataShield Air & Vapour Control Layer 

Construction Notes:

For warm roof applications, thermally broken tube washers should be used. In instances where tube washers are not practical, an appropriate pressure plate should be utilised.


Fasteners should be positioned at 150 mm centres, or as per the site-specific wind load calculations.

Depending on the specified type of air and vapour control layer (AVCL) and the environmental conditions, extrusion of bitumen may be required.

The system build-up and application should adhere to the STRATA issued specification.

All surfaces must be clean, dry, and suitably prepared to accept the waterproofing system.

All details should be installed in full compliance with the most up-to-date NHBC Standards, BS 6229, and STRATA recommendations.



Drawing Title: Membrane Overlap

Drawing Number: SP-SF-W01

Scale: 1:1

Drawn By: E.V.

Date: 26/09/2025

T: 028 9030 2924 | E: technical@stratawaterproofing.com | W: www.stratawaterproofing.com

Copyright Reserved - Please note that this drawing and the copyright therein is the property of Strata Waterproofing Systems and is issued on the understanding that the drawing or any detail thereof will not be divulged to a third party unless written permission is first obtained from Strata Waterproofing Systems. The drawing is valid only when approved by the Architect / Contractor concerned.

This detail is representative of a typical situation and provided for illustration purposes. Insulation thickness shown may differ in accordance with the specified U-value requirement.

