

Key:

StrataPlan Detail Membrane



Hot Air Weld



StrataPlan SF Membrane



StrataTherm Insulation



StrataShield Air & Vapour Control Layer

**Construction Notes:**


Apply treated timber battens to form the gutter, or alternatively you can use the pre-formed StrataPlan Metal as indicated.

Mechanically fix the termination bar or StrataPlan Metal at 150mm centres, or as per the site specific wind-load calculation.

The system build-up and application should adhere to the STRATA issued specification.

All surfaces must be clean, dry, and suitably prepared to accept the waterproofing system.


All details should be installed in full compliance with the most up-to-date NHBC Standards, BS 6229, and STRATA recommendations.

Alternative Detail

Timber batten mechanically fixed to decking

StrataPlan Liquid Sealant (if required)

Termination bar/tube washer with suitable fixing

**Drawing Title:** Built-in Gutter

Drawing Number: SP-SF-W19

Scale: 1:4

Drawn By: E.V.

Date: 26/09/2025

T: 028 9030 2924 | E: technical@stratawaterproofing.com | W: www.stratawaterproofing.com

Copyright Reserved - Please note that this drawing and the copyright therein is the property of Strata Waterproofing Systems and is issued on the understanding that the drawing or any detail thereof shall not be divulged to a third party unless written permission is first obtained from Strata Waterproofing Systems. The drawing is valid only when approved by the Architect/Contractor concerned.

This detail is representative of a typical situation and provided for illustration purposes. Insulation thickness shown may differ in accordance with the specified U-value requirement.

